

# andrewJames

## Family Fit Smoothie Maker



Please read the manual fully before using the appliance and keep the manual safe for future reference.



@andrewjamesltd

## Safety guide

When using any electrical appliance, basic safety precautions should always be followed including:

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised. Keep the appliance and its cord out of reach of children less than 8 years old.
- Always ensure the voltage on the rating label corresponds to the voltage in your home.
- Check the power cord and plug regularly for any damage. If the cord or the plug is damaged, it must be replaced by a qualified electrician or a service repair centre. If in doubt please contact our customer service team.
- The appliance is intended for domestic use only. Industrial or commercial use will void the warranty. The supplier cannot be held responsible for injury or damage if the appliance has been used for anything other than its intended use.
- Incorrect operation and use can damage the appliance and cause injury to the user.
- Do not use the appliance if it has been dropped or damaged in any way. If the unit has been damaged take the unit for examination and

or repair by an authorised service agent.

- Do not immerse or expose the motor assembly, plug or the power cord in water or any other liquid for any reason.
- If the supply cord is damaged, it must be replaced by the manufacturer or by someone who is suitably qualified to avoid a potential hazard.
- Do not let the cord hang over the edge of a table or counter. Ensure that the cord is not in a position where it can be pulled or tripped over accidentally.
- Do not allow the cord to touch hot surfaces and do not place the cord near hot gas, electric burners or in a heated oven.
- Use of an extension cord with this appliance is not recommended. However if it is necessary to use an extension cord, ensure that the extension cord is equal to or

greater than the power consumption of the appliance to avoid overheating of the appliance and extension cord. Do not use any other appliance on the extension cord. Do not place the extension cord in a position where it can be pulled on by children or animals or be tripped over.

- Always operate the appliance on a smooth, even and stable surface.
- Always remove the plug of the appliance safely. Do not pull on the appliances cord to remove the appliance plug from the electrical socket.
- Never handle or operate the appliance with wet hands.
- Do not use the appliance to blend ingredients such as dough, mashed potato, raw meat etc.
- The blender has a safety start

-up system. The appliance will not operate unless it is correctly installed.

- Do not overload the sports bottle. If the motor stalls, turn the appliance off immediately, unplug the unit and let it cool for at least ten minutes.

**Appliance components illustration**



## Assembling and using the appliance

1. Place the sports bottle on a flat level surface with the opening facing upwards. Fill the bottle with ingredients, not exceeding the 600ml maximum level mark.
2. Securely fasten the lid on the appliance so that the base assembly is inside the sports bottle.
3. Turn the sports bottle upside down and place it in the blender base, aligning the arrows on the base assembly with the smoothie maker base. Turn the sports bottle clockwise to lock it into place.
4. Put the appliances plug into the electrical supply and turn the appliance on.
5. Press the control button and the smoothie maker will begin functioning.
6. After all the ingredients are blended, release the switch and rotate the sports bottle anti-clockwise and remove the bottle from the base.
7. Remove the base assembly and attach the spill proof drinking lid or alternatively pour into a suitable container.



## Tips

After using the sports smoothie maker, clean the sports bottle out or alternatively use it as a water or other cool liquid container.

Cut larger pieces of fruit and vegetables into smaller sizes (approx. 2-3cm).

## Maintenance, cleaning & storage of the appliance

- Do not attempt to change or repair parts yourself, please contact our customer service team or seek a professionally qualified person for repairs.
- Always allow a cooling period to occur before beginning cleaning.
- Always clean the appliance after every use and before storage.
- Never immerse the main body, cord or plug into water or any other liquid.
- Never use abrasive chemical cleaners on the appliance. This includes sterilising solutions/ tablets.
- Do not use scouring pads, bleach or other abrasive substances/ solvents to clean the appliance as it can damage the appliance.
- To remove stains and marks, wipe body of the appliance with a slightly dampened cloth in mild soapy water or non-abrasive cleaner. Rinse and dry with a clean, dry soft cloth.

- Always unplug the appliance from the wall socket before storage.
- Clean the appliance thoroughly before storing the appliance.
- Store the appliance with the blade unit in the sports bottle.
- Try to store the appliance in its original packaging.
- Do not wrap the cord around the appliance as it will damage the cord.

## Smoothie recipes

### Pineapple, coconut & mango

1 mango, chunks

1 banana, chopped

100ml coconut milk

50ml milk

100g pineapple, chunks

Handful of ice

### Method

1. Peel and chop the mango, pineapple and banana into chunks. Place into the Sports bottle.
2. Add coconut milk, milk and a handful of ice.
3. Place the lid on and ensure it is locked. Turn the bottle upside down and lock into place on the blender base.
4. Press the control button and blend until smooth.

### **Blueberry & strawberry**

8 Strawberries

50g blueberries

Juice of ½ lime

100ml apple juice

Handful of ice

#### **Method**

1. Hull and half the strawberries.
2. Add blueberries, strawberries, the juice of 1 lime, apple juice to the sports bottle.
3. Add a handful of ice
4. Place the lid on and ensure it is locked. Turn the bottle upside down and lock into place on the blender base.
5. Press the control button and blend until smooth.

### **Tropical orange**

2 oranges

100g pineapple chunks

100ml apple juice

Handful of ice

#### **Method**

1. Peel and chop the orange and pineapple chunks. Place into the Sports bottle.
2. Add the apple juice and a handful of ice.
3. Place the lid on and ensure it is locked. Turn the bottle upside down and lock

into place on the blender base.

4. Press the control button and blend until smooth.

### **Pineapple & passion fruit**

100g pineapple

50ml pineapple juice

2 passion fruit

1 handful of ice

#### **Method**

1. Peel and chop the pineapple into chunks. Place into the sports bottle.
2. Cut 2 passion fruits and scoop out the centres. Add to the sports bottle.
3. Add the pineapple juice and a handful of ice.
4. Place the lid on and ensure it is locked. Turn the bottle upside down and lock into place on the blender base.
5. Press the control button and blend until smooth.

### **Strawberry soya**

150ml soya milk

1 banana

8 strawberries

Vanilla pod

#### **Method**

1. Hull and quarter the strawberries and cut the banana into chunks. Place into



the sports bottle.

2. Slice the vanilla pod and scrape out the centre. Add to the bottle.
3. Add the soya milk and a handful of ice.
4. Place the lid on and ensure it is locked. Turn the bottle upside down and lock into place on the blender base.
5. Press the control button and blend until smooth.

### **Kiwi tang**

2 kiwis

100g pineapple

125ml apple juice

Handful of ice

### **Method**

1. Peel and chop the kiwis into chunks. Place into the sports bottle.
2. Peel and chop the pineapple into chunks. Add to the bottle.
3. Add the apple juice and a handful of ice.
4. Ensure the lid is locked. Turn the speed dial to setting 2.
5. Blend until smooth.

### **Mango and orange**

100ml low fat yogurt

2 oranges

1 mango, chunks

Handful of ice

### **Method**

1. Peel and chop the oranges and mango into chunks. Place into the sports bottle
2. Add the yogurt and a handful of ice.
3. Place the lid on and ensure it is locked. Turn the bottle upside down and lock into place on the blender base.
4. Press the control button and blend until smooth.

### **UK & EU guarantee**

Your new Andrew James product comes with a 24 month guarantee and a 2 year fixed warranty, effective from receipt confirmation. Your receipt or order number is required as proof of purchase date so it is imperative that you keep it safe. This guarantee only applies if the item has been used solely for the use intended, and all instructions have been followed accordingly. Please note this product is only for domestic use only and is not for commercial use.

Abuse of your product will invalidate the guarantee. Returned goods can only be accepted if repackaged properly within the original colour product box, and presented with the original receipt of sale/order number. This does not affect your statutory rights.

Returned products must be cleaned and returned to us in as close to delivery condition as possible.

If your product develops a problem within the first 12 months of the fixed warranty, we will pay all shipping costs to have it returned to us. After 12 months the customer will be liable for the cost of returning the product to us. We will then pay to have the repaired/replaced item shipped back to the customer.

If you wish to return your item for a full refund, you have the right to do so within the first 7 days. For our returns policy please go to:

[www.andrewjamesworldwide.com](http://www.andrewjamesworldwide.com)

Customers are responsible for any taxes applied to our products when they are shipped outside of the EU.

All of our prices are inclusive of VAT.

Once a product has been returned to us, we will aim to repair or replace it within 30 days of receipt.

The guarantee does not cover any defect arising from improper use, damage, build-up of lime scale or repair attempts made by third-parties. Also, the guarantee does not cover normal wear and tear of individual parts.

### **Electrical information**

Always ensure the voltage on the rating label corresponds to the power supply where the product is being used.

**WARNING!** This product must be connected to an earthed electrical power supply. The green/yellow conductor in the

supply cord must be connected to the Earth terminal in the plug. The power supply must have an Earth connection.

Precautions should be followed for safe cable management and connection to the power supply

If a new mains plug needs to be fitted follow the fitting instructions supplied with good quality BS1363A plugs. If in doubt consult a qualified electrician or appliance repair agent.

- Safely dispose of the old plug.
- Connect the brown lead to the live terminal "L" in the new plug.
- Connect the blue lead to the neutral "N" terminal.
- Connect the green/yellow lead to the earth "E" terminal.

Recommended fuse: 13A

If an extension cable is required, it must have an earth conductor. To avoid overheating the extension cable should be rated no less than 13A and be fully unwound before use.

Do not attempt to modify electrical plugs or sockets or attempt to make an alternative connection to the electrical supply.

## Disposal of the appliance

### Waste Electrical & Electronic Equipment (WEEE) Waste & Recycling



### Disposal of Electrical and Electronic Waste

Non-household waste. This product must not be disposed of together with ordinary household waste.

Separate collection of used products, batteries and packaging allows the recovery and recycling of materials. Re-use of materials helps prevent environmental pollution and reduces the demand for raw materials.

Local authorities, retailers and collection organisations may provide for separate collection of electrical products, batteries and packaging.

## Contact details

Andrew James UK LTD

Unit 1

P C Henderson Premises

Bowburn North Industrial Estate

Bowburn

Co Durham

DH6 5NG

### Customer Service / Technical Support

Telephone: 0844 335 8464

Email:

[customerservices@andrewjamesworldwide.com](mailto:customerservices@andrewjamesworldwide.com)

**Web:**

[www.andrewjamesworldwide.com](http://www.andrewjamesworldwide.com)

**Twitter:** @andrewjamesltd

**Facebook:** Andrew James

Copyright Andrew James

Pour la version française de ce notice  
veuillez visiter notre site:

[www.andrewjamesworldwide.com](http://www.andrewjamesworldwide.com)

Bitte finden Sie die deutsche Version  
dieser Bedienungsanleitung auf unserer:

[www.andrewjamesworldwide.com](http://www.andrewjamesworldwide.com)

AJ000716 / AJ000717

09/2016